

**⚠ WARNING**

To prevent entanglement injury, never place gym in a crib or playpen. Never add strings, ties or other products to the gym.

- 1 Fit the ends of the legs into the sockets in the arch. Push to "snap" in place.
Hint: The legs are designed to fit into the arch one way. If they do not seem to fit, try the other side of the arch!
- 2 Hook the toys to any of the loops around the gym.
- 3 Press the button on each end of the arch to open and close the legs.

 **CONSUMER ASSISTANCE**
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

 **service.fisher-price.com**

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

- Please keep this instruction sheet for future reference, as it contains important information.
- Adult assembly is required. No tools required.
- Wipe this toy with a clean, damp cloth.