



C5523

www.fisher-price.com



Please keep this instruction sheet for future reference,
as it contains important information.

Requires three "C" batteries (included).

An adult must remove this product from the package and install batteries.

Tool required to remove product from package and for battery replacement:
Phillips screwdriver (not included).



IncrediBlock™

Before First Time Use

CAUTION

Please keep small parts such as the plastic tabs out of children's reach.
Throw the plastic tab away.

Note: A plastic tab was attached to the toy for in-store demonstration purposes. While the tab may have already been removed, check the toy to be sure. If the plastic tab is still attached, pull and remove the tab from the toy. Throw the plastic tab away.

Battery Replacement




For best performance, we recommend replacing the batteries that came with this toy with three, new alkaline "AA" (LR6) batteries.

- Locate the battery compartment on the bottom of the toy. Loosen the screws in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door.
- Remove and dispose of worn batteries. Insert three "C" (LR14) **alkaline** batteries.

Hint: We recommend using **alkaline** batteries for longer battery life.

- Replace the battery compartment door and tighten the screws with a Phillips screwdriver. Do not over-tighten.
- When sounds, or motions from this toy become faint or stop, it's time for an adult to change the batteries!

Battery Safety Information



In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of product in a fire. The batteries may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

Five Sides of Busy Play!



- Locate the power/volume switch on the bottom of the toy.
- Slide the switch to the desired position: on with low volume 🔊 or on with high volume 🔊 . When your child is finished playing with the toy, slide the power/volume switch to the off 🏠 position.

Spin & Learn



- Place any of the eight special blocks upright in the center of the carousel and press down. Hear about what's inside of each block followed by a fun sound effect!

Note: The block recognition feature only works with the eight blocks included with this toy. Other Peek-a-Blocks™ (sold separately) produce only a sound effect.


- Or, press the action button to hear a fun tune and see the carousel spin around with flashing lights.

Stack & Spill



- Drop blocks into any of the three channels to hear a song or a fun sound effect.
- Press the lever and watch the blocks spill out!

Drop & Tumble



- Drop the blocks through the top slots and watch them tumble through the side.

Sort & Store



- Fit blocks through the openings for storage. Open the door to play again!

Plug & Play



- Plug blocks into either of the square openings.

Consumer Information

Visit us on line at
www.service.fisher-price.com

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-5437**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Write to us at: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse this toy.

FCC Note (United States Only)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

For countries outside the United States:

CANADA: Questions? **1-800-432-5437**. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.

GREAT BRITAIN: [Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303; www.service.mattel.com/uk](http://www.service.mattel.com/uk)

AUSTRALIA: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND: 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.