


Fisher-Price®

[www.fisher-price.com](http://www.fisher-price.com)






M2100




**GeoTrax**  
Rail & Road System

# Parts

- A. 2 Small Flags
- B. Large Flag
- C. Roof
- D. 4 Supports
- E. Base




# Assembly



- First, fit the tabs on the front of the roof into the slots in the front of the base **A**.
- Then, press the top of the roof to "snap" the side tabs into place **B**.

- "Snap" the supports into the underside of the base.
  - "Snap" the flags into the roof.
- Assembly is now complete.**




## So Many Ways to Play!



- Watch the panels spin when a train crosses the bridge.


## Multiple Levels of Track Layouts!

Track not included and sold separately.




- To build a ground-level layout, separate the bridge assembly from the supports and place it on a flat surface.
- Attach straight tracks (sold separately) to either end of the bridge assembly.

- Use supports and straight tracks (each sold separately) to build an elevated assembly.



- You can also use an Elevation Track Pack™ (sold separately) to access the bridge.
- Attach ramp assemblies (sold separately) to the ends of the bridge.



# Fisher-Price®



Visit [www.fisher-price.com](http://www.fisher-price.com) to see  
the entire world of GeoTrax® accessories!

Please keep this instruction sheet for future reference,  
as it contains important information.

Adult assembly is required.

No tools needed for assembly.

Wipe the toy with a clean, damp cloth. Do not immerse.



## CONSUMER ASSISTANCE

Call toll free: 1-800-432-5437 (US & Canada only)  
M-F 9AM to 7PM / SAT 11AM to 5PM (EST)

[service.fisher-price.com](http://service.fisher-price.com)

Write to us at: Fisher-Price® Consumer Relations,  
636 Girard Avenue, East Aurora, New York 14052.

Hearing-impaired consumers using TTY/TDD equipment,  
please call 1-800-382-7470.

For countries outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,  
Mississauga, Ontario L5R 3W2; [www.service.mattel.com](http://www.service.mattel.com).

Great Britain: [Mattel UK Ltd, Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline: 01628 500303,  
www.service.mattel.com/uk](http://www.service.mattel.com/uk)

Australia: Mattel Australia Pty. Ltd., 658 Church Street,  
Locked Bag #870, Richmond, Victoria 3121 Australia.  
Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive,  
Albany 1331, Auckland.

Asia: Mattel East Asia Ltd, Room 1106, South Tower,  
World Finance Centre, Harbour City, Tsimshatsui, HK, China.