

Fisher-Price®

WARNING

TO AVOID SERIOUS INJURY:

- Continuous adult supervision is required.
- Never use near cars and other motor vehicles, near streets, steps, sloped driveways, hills, roadways, alleys, swimming pools or other bodies of water.
- Always wear shoes.
- Never allow more than one rider.

- Keep instruction sheets for future reference, as they contain important information.
- Adult assembly is required.
- Required tools: Hammer, Phillips Screwdriver and Scrap Block of Wood (not included).
- Age: 2 - 6 years; Weight Limit: 60 lbs (27 kg).

Fisher Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2011 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.