

**Fisher-Price®**

**INTERACTV™**

**DVD BASED LEARNING SYSTEM**



# ***Manufacturer's Code Booklet***

|   | MANUFACTURER       | MODEL      | CODE                                                                                                                           |
|---|--------------------|------------|--------------------------------------------------------------------------------------------------------------------------------|
| # | 3DLabs             | ALL MODELS | 0463                                                                                                                           |
| A | Acoustic Solutions | ALL MODELS | 1113                                                                                                                           |
|   | Advent             | ALL MODELS | 1053                                                                                                                           |
|   | AEG                | ALL MODELS | 1069, 1134, 1114                                                                                                               |
|   | Afreey             | ALL MODELS | 1130                                                                                                                           |
|   | Aim                | ALL MODELS | 1029                                                                                                                           |
|   | Aiwa               | AVD57      | 0921                                                                                                                           |
|   | Aiwa               | XDAX1      | 1022                                                                                                                           |
|   | Aiwa               | XDDV370    | 0465                                                                                                                           |
|   | Aiwa               | XDDW1      | 0465                                                                                                                           |
|   | Aiwa               | ALL MODELS | 0465, 0456, 1022, 1063, 1064, 0921                                                                                             |
|   | Akai               | DVPS760    | 0884                                                                                                                           |
|   | Akai               | ALL MODELS | 1152, 0884, 0878, 1139, 1051, 1124, 1114                                                                                       |
|   | Akira              | ALL MODELS | 1129, 1029                                                                                                                     |
|   | Alba               | ALL MODELS | 0456, 1129, 0460, 1132, 1124, 1045, 1044                                                                                       |
|   | Albatros           | ALL MODELS | 1111, 1110, 1067                                                                                                               |
|   | Alco               | ALL MODELS | 0878*                                                                                                                          |
|   | Allegro            | ABV341     | 1136                                                                                                                           |
|   | Allegro            | ALL MODELS | 1081, 0475*, 1136                                                                                                              |
|   | Alpine             | ALL MODELS | 1098                                                                                                                           |
|   | Amitech            | ALL MODELS | 1069, 1134, 1056                                                                                                               |
|   | Amoisonic          | ALL MODELS | 1152                                                                                                                           |
|   | Amstrand           | ALL MODELS | 1124                                                                                                                           |
|   | AMW                | T352       | 1140                                                                                                                           |
|   | AMW                | ALL MODELS | 1140, 1141                                                                                                                     |
|   | Anaba              | ALL MODELS | 1143                                                                                                                           |
|   | Anam               | ALL MODELS | 0894, 0201                                                                                                                     |
|   | Anim               | ALL MODELS | 0201                                                                                                                           |
|   | Apex               | AD1010W    | 0437                                                                                                                           |
|   | Apex               | AD1100W    | 1067                                                                                                                           |
|   | Apex               | AD1110W    | 0437                                                                                                                           |
|   | Apex               | AD1200     | 0437                                                                                                                           |
|   | Apex               | AD1201     | 1067                                                                                                                           |
|   | Apex               | AD1225     | 1006                                                                                                                           |
|   | Apex               | AD1500     | 0437                                                                                                                           |
|   | Apex               | AD1600     | 0437                                                                                                                           |
|   | Apex               | AD1700M    | 0437                                                                                                                           |
|   | Apex               | Ad2100     | 0460                                                                                                                           |
|   | Apex               | AD2500     | 1030                                                                                                                           |
|   | Apex               | AD2600     | 1006                                                                                                                           |
|   | Apex               | AD500      | 0437                                                                                                                           |
|   | Apex               | AD660      | 0455                                                                                                                           |
|   | Apex               | AD700      | 0455                                                                                                                           |
|   | Apex               | ADR1000    | 0437                                                                                                                           |
|   | Apex               | ADV3800    | 1006                                                                                                                           |
|   | Apex               | GT2015DV   | 1009                                                                                                                           |
|   | Apex               | GT2715DV   | 1009                                                                                                                           |
|   | Apex               | MD100      | 1059                                                                                                                           |
|   | Apex               | PD100      | 1075                                                                                                                           |
|   | Apex               | PD450      | 1060                                                                                                                           |
|   | Apex               | PD650      | 1060                                                                                                                           |
|   | Apex               | ALL MODELS | 0455, 1132, 0460, 0437, 0921, 0461, 0485, 1067, 1068, 1069, 1070*, 1073*, 1075, 1030, 1031, 1010, 1009, 1006, 1089, 1059, 1060 |
|   | Arena              | ALL MODELS | 1139                                                                                                                           |
|   | Aria               | ALL MODELS | 1145                                                                                                                           |

| MANUFACTURER              | MODEL      | CODE                                                 |
|---------------------------|------------|------------------------------------------------------|
| Arianet                   | ALL MODELS | 1145                                                 |
| Ariston Acoustics         | ALL MODELS | 1035, 1034                                           |
| A-Trend                   | ALL MODELS | 1130                                                 |
| Audiosonic                | ALL MODELS | 1152                                                 |
| Audiovox                  | D1530      | 1132                                                 |
| Audiovox                  | D1730      | 1132                                                 |
| Audiovox                  | D1800      | 0437                                                 |
| Audiovox                  | D1830      | 1132                                                 |
| Audiovox                  | DVD1210    | 1042                                                 |
| Audiovox                  | ME20       | 1042                                                 |
| Audiovox                  | PE701      | 1132                                                 |
| Audiovox                  | PE702      | 1042                                                 |
| Audiovox                  | VBP4000    | 1042                                                 |
| Audiovox                  | ALL MODELS | 0878, 0437, 1042, 1046, 1132                         |
| Auvio                     | ALL MODELS | 1036, 1037                                           |
| AWA                       | ALL MODELS | 1113                                                 |
| <b>B</b> Baier            | ALL MODELS | 0986                                                 |
| Black Diamand             | ALL MODELS | 1124                                                 |
| Blaupunkt                 | ALL MODELS | 1132, 0460, 0658*                                    |
| Blue Parade               | ALL MODELS | 0453                                                 |
| Blue Sky                  | ALL MODELS | 0457, 0437, 0456, 1129, 1024, 1037                   |
| Boman                     | ALL MODELS | 0881                                                 |
| Bose                      | Bose321    | 0489                                                 |
| Bose                      | ALL MODELS | 0489                                                 |
| Brain Wave                | ALL MODELS | 1069, 1134                                           |
| Brandt                    | ALL MODELS | 1120, 0457                                           |
| Brooksonic                | ALL MODELS | 0925*, 0456                                          |
| Bush                      | ALL MODELS | 1152, 0456, 1129, 0460, 1132, 1029, 1045, 1124, 1123 |
| <b>C</b> California Audio | ALL MODELS | 0445                                                 |
| Cambridge                 | SoundWorks | 1143                                                 |
| Cambridge                 | ALL MODELS | 1143, 1046, 1121                                     |
| Cary                      | ALL MODELS | 0459                                                 |
| CAT                       | ALL MODELS | 1129, 0448, 1055, 1054, 1053                         |
| Celestial                 | ALL MODELS | 0437, 1006                                           |
| Centrex                   | ALL MODELS | 0437, 1030                                           |
| Centrum                   | ALL MODELS | 0448, 1124                                           |
| CGE                       | ALL MODELS | 1044                                                 |
| cineULTRA                 | ALL MODELS | 1129                                                 |
| CineVision                | ALL MODELS | 1081, 1024                                           |
| Classic                   | PV7000     | 1047                                                 |
| Classic                   | ALL MODELS | 1047, 1141, 1113                                     |
| Claton                    | ALL MODELS | 1124                                                 |
| Clatronic                 | ALL MODELS | 1114                                                 |
| Coby                      | DVD707     | 1021                                                 |
| Coby                      | DVD7500    | 1115                                                 |
| Coby                      | ALL MODELS | 1029, 1021, 1113, 1115                               |
| Concept                   | ALL MODELS | 0460, 0877                                           |
| Conia                     | ALL MODELS | 1152, 0437, 1139, 1109                               |
| Continental Edison        | ALL MODELS | 1141                                                 |
| Crown                     | ALL MODELS | 1152, 1069, 1134, 0457                               |
| C-Tech                    | ALL MODELS | 0484                                                 |
| Cybercom                  | ALL MODELS | 1005                                                 |
| Cyberhome                 | CHDVD300   | 1130                                                 |
| CyberHome                 | ALL MODELS | 1130                                                 |
| Cytron                    | ALL MODELS | 0884, 0457                                           |

| MANUFACTURER    | MODEL      | CODE                                                              |
|-----------------|------------|-------------------------------------------------------------------|
| <b>D</b> Daewoo | DV6T834B   | 1106                                                              |
| Daewoo          | DVG3000D   | 1069                                                              |
| Daewoo          | DVG4000S   | 1061                                                              |
| Daewoo          | DVG5200S   | 1154                                                              |
| Daewoo          | DVG9000N   | 1061                                                              |
| Daewoo          | ALL MODELS | 1130, 1141, 0884, 1106*, 1129, 1130, 1069, 1134, 1029, 1061, 1154 |
| Dalton          | ALL MODELS | 1055                                                              |
| Dansai          | ALL MODELS | 1069, 1134, 0881                                                  |
| Dantax          | ALL MODELS | 1045                                                              |
| Dargon          | ALL MODELS | 1005                                                              |
| Daytek          | ALL MODELS | 1141                                                              |
| Dayton          | ALL MODELS | 1141                                                              |
| DEC             | ALL MODELS | 1129, 1029                                                        |
| Decca           | ALL MODELS | 1069, 1134                                                        |
| Denon           | DVD1000    | 0886                                                              |
| Denon           | DVD1500KE3 | 0886                                                              |
| Denon           | DVD2800    | 0886                                                              |
| Denon           | ALL MODELS | 0886, 0477, 0472, 0478, 0439, 0869, 0481, 0482, 0444, 0884, 0452  |
| Denver          | ALL MODELS | 1129, 1029, 1114                                                  |
| Denzel          | ALL MODELS | 1141                                                              |
| Desay           | ALL MODELS | 1102                                                              |
| Diamond         | ALL MODELS | 1029, 0457, 0484, 1045, 1046                                      |
| Digihome        | ALL MODELS | 1124                                                              |
| digiRED         | ALL MODELS | 1132, 0460                                                        |
| Digital I       | ALL MODELS | 1145                                                              |
| Digitor         | ALL MODELS | 1069                                                              |
| Digitrex        | ALL MODELS | 1067, 0437                                                        |
| DIK             | ALL MODELS | 1005                                                              |
| Dinamic         | ALL MODELS | 1114                                                              |
| Disney          | DVD2000C   | 0487                                                              |
| Disney          | ALL MODELS | 0487                                                              |
| DiViDo          | ALL MODELS | 0884                                                              |
| DK              | ALL MODELS | 1005                                                              |
| DMTECH          | ALL MODELS | 0881, 0878                                                        |
| Dual            | ALL MODELS | 0457, 1141, 0881, 0878, 1124, 1113                                |
| Duraband        | ALL MODELS | 0448                                                              |
| DVD2000         | ALL MODELS | 0470, 1033                                                        |
| DVX             | ALL MODELS | 1041                                                              |
| <b>E</b> E-Boda | ALL MODELS | 1045                                                              |
| Eclips          | ALL MODELS | 1045                                                              |
| Electrohome     | ALL MODELS | 1069, 1134                                                        |
| Elin            | ALL MODELS | 1069, 1134                                                        |
| Ellion          | ALL MODELS | 1056                                                              |
| Elta            | ALL MODELS | 1152, 1069, 1134, 0878, 1114                                      |
| Emerson         | DVD2000    | 1136                                                              |
| Emerson         | EWD7002    | 0487                                                              |
| Emerson         | ALL MODELS | 1151, 1136, 0884, 0487*, 1097                                     |
| Encore          | ALL MODELS | 1130                                                              |
| Enterprise      | ALL MODELS | 1136, 1097                                                        |
| Enzer           | ALL MODELS | 1141, 0438                                                        |
| esa             | DP3220     | 1004                                                              |
| esa             | ALL MODELS | 1004                                                              |
| Escent          | DVDM100    | 0451                                                              |
| Escent          | ALL MODELS | 0451                                                              |

| MANUFACTURER       | MODEL      | CODE                                                       |
|--------------------|------------|------------------------------------------------------------|
| <b>F</b> Farenheit | ALL MODELS | 1144, 1038                                                 |
| Ferguson           | ALL MODELS | 0457                                                       |
| Finlux             | ALL MODELS | 1136, 1069, 1134, 0881                                     |
| Firstline          | ALL MODELS | 1136, 0484, 0457                                           |
| Fisher             | DVDS1000   | 0436                                                       |
| Fisher             | DVDS1100   | 0436                                                       |
| Fisher             | DVDS1500   | 0436                                                       |
| Fisher             | DVDS2000   | 0436                                                       |
| Fisher             | ALL MODELS | 1137, 0445, 1154, 0436                                     |
| Funai              | ALL MODELS | 1074, 0456                                                 |
| Funi               | ALL MODELS | 1019                                                       |
| <b>G</b> GE        | GE1401P    | 0450                                                       |
| GE                 | ALL MODELS | 0450, 0460, 1132, 0441, 1108                               |
| Genica             | ALL MODELS | 1102                                                       |
| Global Solutions   | ALL MODELS | 0484                                                       |
| Global Sphere      | ALL MODELS | 0484                                                       |
| Goldstar           | ALL MODELS | 1136, 0475                                                 |
| Goodmans           | ALL MODELS | 1152, 0881, 0878, 1030, 0457, 1045                         |
| Go-Video           | DP7030     | 1008                                                       |
| Go-Video           | DVR4300    | 1107                                                       |
| Go-Video           | DVR5000    | 1107                                                       |
| Go-Video           | GVP5850    | 0460, 1131                                                 |
| Go-Video           | ALL MODELS | 1128, 0881, 1107, 0446, 0466, 1076, 1008, 0460, 1113       |
| GPX                | ALL MODELS | 1129, 1005                                                 |
| Gradiente          | ALL MODELS | 0457                                                       |
| Graetz             | ALL MODELS | 1141                                                       |
| Greenhill          | ALL MODELS | 1132, 0878, 0460                                           |
| Grundig            | ALL MODELS | 0457, 0436, 0456, 0438, 0884, 0878, 1045, 0463, 1124, 1112 |
| Grunkel            | ALL MODELS | 1069, 1134                                                 |
| <b>H</b> H&B       | ALL MODELS | 1124                                                       |
| Haaz               | ALL MODELS | 0484                                                       |
| Hanseatic          | ALL MODELS | 1136                                                       |
| Harmon Kardon      | DVD 25     | 1088                                                       |
| Harmon Kardon      | ALL MODELS | 0468, 1028, 1025, 1088                                     |
| HDT                | ALL MODELS | 0884                                                       |
| He                 | ALL MODELS | 1113                                                       |
| HenB               | ALL MODELS | 1124                                                       |
| Himage             | ALL MODELS | 1041, 1040                                                 |
| Himax              | ALL MODELS | 1037                                                       |
| Hitachi            | DVP315     | 0447                                                       |
| Hitachi            | ALL MODELS | 1141, 0447, 0464, 1072                                     |
| Hiteker            | ALL MODELS | 0437, 1031                                                 |
| HMC                | ALL MODELS | 1114                                                       |
| Home Electronics   | ALL MODELS | 1113                                                       |
| Hypson             | ALL MODELS | 1035                                                       |
| Hyundai            | ALL MODELS | 0881, 1058, 1057, 1056                                     |
| <b>I</b> i2dvd     | ALL MODELS | 1122                                                       |
| Ingelen            | ALL MODELS | 1114                                                       |
| Initial            | ALL MODELS | 0460, 1132                                                 |
| Integra            | ALL MODELS | 0488                                                       |
| IRT                | ALL MODELS | 0881                                                       |
| ISP                | ALL MODELS | 0456                                                       |
| <b>J</b> Jaton     | ALL MODELS | 1141                                                       |
| JBL                | ALL MODELS | 0468, 0022*, 1028                                          |

| MANUFACTURER     | MODEL      | CODE                                     |
|------------------|------------|------------------------------------------|
| Jeken            | ALL MODELS | 1129, 1029                               |
| Jensen           | ALL MODELS | 1053                                     |
| Jindian          | ALL MODELS | 0484                                     |
| JMB              | ALL MODELS | 0456                                     |
| JNL              | ALL MODELS | 1103                                     |
| JVC              | HRXVC1U    | 1150                                     |
| JVC              | HRXVC25U   | 1150                                     |
| JVC              | HRXVC27    | 1150                                     |
| JVC              | MXJ70      | 0485                                     |
| JVC              | XV421BK    | 0485                                     |
| JVC              | XV521BK    | 0485                                     |
| JVC              | XVM555BK   | 0485                                     |
| JVC              | XVM567GD   | 0485                                     |
| JVC              | XVN30BK    | 0485                                     |
| JVC              | XVN33SL    | 0485                                     |
| JVC              | XVN3SL     | 0485                                     |
| JVC              | XVN50BK    | 0485                                     |
| JVC              | XVN55SL    | 0485                                     |
| JVC              | XVS200     | 0485                                     |
| JVC              | XVS300BK   | 0485                                     |
| JVC              | XVS302SL   | 0485                                     |
| JVC              | XVS30BK    | 0485                                     |
| JVC              | XVS402SL   | 0485                                     |
| JVC              | XVS40BK    | 0485                                     |
| JVC              | XVS45BK    | 0485                                     |
| JVC              | XVS500BK   | 0485                                     |
| JVC              | XVS502SL   | 0485                                     |
| JVC              | XVS550SL   | 0485                                     |
| JVC              | XVS62SL    | 0485                                     |
| JVC              | XVS65SL    | 0485                                     |
| JVC              | XVSA70BK   | 0485                                     |
| JVC              | ALL MODELS | 1144, 0461, 0485, 0451, 1133, 1150, 0463 |
| Jwin             | ALL MODELS | 1138                                     |
| <b>K</b> Karcher | ALL MODELS | 0881                                     |
| Kendo            | ALL MODELS | 1129                                     |
| Kenwood          | ALL MODELS | 0452, 0480, 0482, 1122                   |
| Kiiro            | ALL MODELS | 1069, 1134                               |
| King DHome       | ALL MODELS | 0484                                     |
| Kiss             | ALL MODELS | 1141                                     |
| KLH              | ALL MODELS | 1132, 0448, 0878*, 0460, 1013            |
| Konka            | ALL MODELS | 1099, 1116, 1117                         |
| Koss             | KD270      | 0457                                     |
| Koss             | ALL MODELS | 0457*, 1003                              |
| Krell            | ALL MODELS | 1095                                     |
| Kyocera          | ALL MODELS | 0869, 0481, 0482, 0439                   |
| <b>L</b> Lasonic | ALL MODELS | 0484                                     |
| Lawson           | ALL MODELS | 0884, 0484                               |
| Lecson           | ALL MODELS | 1121                                     |
| Legacy           | ALL MODELS | 1039                                     |
| Lenco            | ALL MODELS | 1129, 1069, 1134, 1029, 0457             |
| Lenoxx           | ALL MODELS | 1152, 0448                               |
| Lexia            | ALL MODELS | 1129                                     |
| Lexicon          | ALL MODELS | 1093, 1094                               |
| Lg               | ALL MODELS | 1081*, 1136, 1097, 0475                  |
| Lifetec          | ALL MODELS | 0457                                     |
| Limit            | ALL MODELS | 0484                                     |

| MANUFACTURER      | MODEL       | CODE                                                                   |
|-------------------|-------------|------------------------------------------------------------------------|
| Loewe             | ALL MODELS  | 0463                                                                   |
| LogicLab          | ALL MODELS  | 0484                                                                   |
| Logix             | ALL MODELS  | 0884, 0881                                                             |
| Lumatron          | ALL MODELS  | 0884                                                                   |
| Luxman            | ALL MODELS  | 0464                                                                   |
| Luxor             | ALL MODELS  | 1030                                                                   |
| LXI               | ALL MODELS  | 0553*                                                                  |
| <b>M</b> Magnavox | 27MDTR10S   | 1153                                                                   |
| Magnavox          | 27MDTR20/17 | 1074                                                                   |
| Magnavox          | DVD611      | 0463                                                                   |
| Magnavox          | MDV422      | 1086                                                                   |
| Magnavox          | MDV530      | 0463                                                                   |
| Magnavox          | PLDVD01     | 0463, 1023                                                             |
| Magnavox          | ALL MODELS  | 1153, 1074, 0477, 0472, 0478, 0870, 0463, 0451, 0487, 0435, 1023, 1086 |
| Magnex            | ALL MODELS  | 1045                                                                   |
| Manhattan         | ALL MODELS  | 0884                                                                   |
| Marantz           | ALL MODELS  | 0463, 1080, 1086, 1087                                                 |
| Mark              | ALL MODELS  | 1124, 1049, 0451                                                       |
| Matsui            | ALL MODELS  | 0456, 0457                                                             |
| MBO               | ALL MODELS  | 1152, 1113                                                             |
| MDS               | ALL MODELS  | 1129, 1029                                                             |
| Mediencom         | ALL MODELS  | 1101                                                                   |
| Medion            | ALL MODELS  | 0881, 1005, 0457                                                       |
| Memorex           | DVD2000     | 0487                                                                   |
| Memorex           | MVD2027     | 1005                                                                   |
| Memorex           | MVD2256     | 0456                                                                   |
| Memorex           | ALL MODELS  | 0456, 0487, 1005, 1124                                                 |
| Meridian          | ALL MODELS  | 1092                                                                   |
| Metz              | ALL MODELS  | 0453                                                                   |
| Mico              | ALL MODELS  | 1045, 1046                                                             |
| Micromaxx         | ALL MODELS  | 0456                                                                   |
| Micromedia        | ALL MODELS  | 0451, 0463                                                             |
| Micromega         | ALL MODELS  | 0463                                                                   |
| Microsoft         | ALL MODELS  | 0450                                                                   |
| Microstar         | ALL MODELS  | 1005                                                                   |
| Minato            | ALL MODELS  | 0986                                                                   |
| Minax             | ALL MODELS  | 1124                                                                   |
| Minoka            | ALL MODELS  | 1069, 1134                                                             |
| Mintek            | RC320H      | 0460, 1132                                                             |
| Mintek            | ALL MODELS  | 1132, 0460, 0469                                                       |
| Mitsubishi        | DD4020      | 0470                                                                   |
| Mitsubishi        | DD4030      | 0470                                                                   |
| Mitsubishi        | DD6030      | 0470                                                                   |
| Mitsubishi        | DD6040      | 0470                                                                   |
| Mitsubishi        | ALL MODELS  | 0477, 0472, 0478, 0470, 1124                                           |
| Monyka            | ALL MODELS  | 1141                                                                   |
| MP                | ALL MODELS  | 1037                                                                   |
| MPX               | ALL MODELS  | 1037                                                                   |
| Mustek            | ALL MODELS  | 1113                                                                   |
| Mx Onda           | ALL MODELS  | 1045, 1046, 0457                                                       |
| Myryad            | ALL MODELS  | 0466, 1091                                                             |
| <b>N</b> NAD      | ALL MODELS  | 1135, 1136, 0477, 0472, 0478, 0894                                     |
| Naiko             | ALL MODELS  | 1069, 1134                                                             |
| Nakamichi         | ALL MODELS  | 1090                                                                   |
| NEC               | ALL MODELS  | 1135, 1136, 0894                                                       |

| MANUFACTURER     | MODEL      | CODE                                                                                                                               |
|------------------|------------|------------------------------------------------------------------------------------------------------------------------------------|
| Nesa             | ALL MODELS | 1132, 0460                                                                                                                         |
| Neufunk          | ALL MODELS | 1141                                                                                                                               |
| NextBase         | ALL MODELS | 1058                                                                                                                               |
| Nintaus          | ALL MODELS | 1142                                                                                                                               |
| Norcent          | ALL MODELS | 1131, 0448, 1141, 1047                                                                                                             |
| Nordmende        | ALL MODELS | 1005                                                                                                                               |
| Noriko           | ALL MODELS | 0986                                                                                                                               |
| <b>O</b> Okano   | ALL MODELS | 0986                                                                                                                               |
| Omni             | ALL MODELS | 1130, 1129, 1029, 1152                                                                                                             |
| Onix             | ALL MODELS | 1051                                                                                                                               |
| Onkyo            | ALL MODELS | 0488, 0032*, 0451, 0553                                                                                                            |
| Optimus          | ALL MODELS | 0453, 0474, 0458                                                                                                                   |
| Optiview         | ALL MODELS | 1143                                                                                                                               |
| Orion            | ALL MODELS | 0456, 1124                                                                                                                         |
| Oritron          | DVD100     | 0457                                                                                                                               |
| Oritron          | DVD3116    | 0457                                                                                                                               |
| Oritron          | ALL MODELS | 1067, 0457                                                                                                                         |
| <b>P</b> Pacific | ALL MODELS | 0484, 0878, 1005, 1124                                                                                                             |
| Palladium        | ALL MODELS | 0456                                                                                                                               |
| Palsonic         | ALL MODELS | 1152, 1139, 0437, 1123                                                                                                             |
| Panasonic        | DMRE30     | 0452                                                                                                                               |
| Panasonic        | DMRE50     | 0452                                                                                                                               |
| Panasonic        | DVDF84     | 0869                                                                                                                               |
| Panasonic        | DVDLV55    | 0452                                                                                                                               |
| Panasonic        | DVDLV60    | 0452                                                                                                                               |
| Panasonic        | DVDRP56    | 0482                                                                                                                               |
| Panasonic        | DVDRV20    | 0452                                                                                                                               |
| Panasonic        | DVDRV30    | 0452                                                                                                                               |
| Panasonic        | DVDRV31K   | 0452                                                                                                                               |
| Panasonic        | DVDRV32K   | 0869                                                                                                                               |
| Panasonic        | DVDRV65    | 0452                                                                                                                               |
| Panasonic        | DVDS25     | 0452                                                                                                                               |
| Panasonic        | DVDS27     | 0481                                                                                                                               |
| Panasonic        | DVDS35     | 0869                                                                                                                               |
| Panasonic        | PVD4742    | 1084                                                                                                                               |
| Panasonic        | PVD4743    | 0439                                                                                                                               |
| Panasonic        | PVD4752    | 0452                                                                                                                               |
| Panasonic        | PVDM2791   | 1083                                                                                                                               |
| Panasonic        | ALL MODELS | 0439, 0869, 0481, 0482, 0445, 1096, 0479, 1020, 0486, 0477, 0472, 0478, 0434, 0886, 0452, 0488, 1011, 1083, 1084, 1085, 1043, 0452 |
| Panda            | ALL MODELS | 0881                                                                                                                               |
| Philco           | ALL MODELS | 1114, 1152, 1045, 1044                                                                                                             |
| Philips          | DVD711/171 | 1086, 1087, 1023                                                                                                                   |
| Philips          | DVD712     | 0463                                                                                                                               |
| Philips          | DVD724AT   | 0463                                                                                                                               |
| Philips          | DVD726     | 0463                                                                                                                               |
| Philips          | DVD750VR   | 1023                                                                                                                               |
| Philips          | DVDR985    | 1027                                                                                                                               |
| Philips          | ALL MODELS | 0463, 0870, 0451, 0435, 1074, 1027, 1023, 1105, 1080, 1086, 1087, 1082                                                             |
| Phonotrend       | ALL MODELS | 1129                                                                                                                               |
| Pioneer          | CUDVD22    | 0453                                                                                                                               |
| Pioneer          | DV440      | 0453                                                                                                                               |
| Pioneer          | DV45A      | 0453                                                                                                                               |

| MANUFACTURER        | MODEL      | CODE                                                                                       |
|---------------------|------------|--------------------------------------------------------------------------------------------|
| Pioneer             | V434       | 0453                                                                                       |
| Pioneer             | ALL MODELS | 0477, 0472, 0478, 0453, 0458, 0869, 1146, 1014, 0021*, 1078, 1079, 1077, 0481              |
| Pointer             | ALL MODELS | 1069, 1134                                                                                 |
| Polaroid            | PDV0700    | 1141                                                                                       |
| Polaroid            | ALL MODELS | 1141, 1115                                                                                 |
| Polkaudio           | ALL MODELS | 0463                                                                                       |
| Popular_Mech        | ALL MODELS | 0471                                                                                       |
| Prima               | ALL MODELS | 1053                                                                                       |
| Proline             | ALL MODELS | 0437, 0878, 0457                                                                           |
| Proscan             | ALL MODELS | 0450, 0441                                                                                 |
| Prosonic            | ALL MODELS | 1129                                                                                       |
| Provision           | ALL MODELS | 1129                                                                                       |
| Pyle                | ALL MODELS | 1038, 1048                                                                                 |
| <b>Q</b> Quasar     | ALL MODELS | 0445, 1039                                                                                 |
| Qwestar             | ALL MODELS | 1039, 1048                                                                                 |
| <b>R</b> Radionette | ALL MODELS | 1136                                                                                       |
| Raite               | ALL MODELS | 1141                                                                                       |
| RCA                 | DRC105N    | 0450                                                                                       |
| RCA                 | DRC220N*   | 0450                                                                                       |
| RCA                 | DRC350N    | 0450                                                                                       |
| RCA                 | DRC6100N*  | 0450, 0441                                                                                 |
| RCA                 | RC5220     | 0450                                                                                       |
| RCA                 | RC5231Z    | 0450                                                                                       |
| RCA                 | RC5240P    | 0450                                                                                       |
| RCA                 | RTDVD1     | 0450                                                                                       |
| RCA                 | ALL MODELS | 0450, 0460, 0477, 0472, 0478, 0878*, 0894, 0201*, 0440, 0441, 1012, 1007, 0457, 0453, 1132 |
| Realistic           | ALL MODELS | 0474                                                                                       |
| REC                 | ALL MODELS | 0452, 0482, 1123                                                                           |
| Red Star            | ALL MODELS | 1134, 1069, 1114                                                                           |
| Reoc                | ALL MODELS | 0986, 0484                                                                                 |
| Revoy               | ALL MODELS | 1129                                                                                       |
| Rex                 | ALL MODELS | 1051                                                                                       |
| Rio Audio           | ALL MODELS | 1136                                                                                       |
| Roadstar            | ALL MODELS | 1129, 1124, 1152                                                                           |
| Ronin               | ALL MODELS | 1141                                                                                       |
| Rotel               | ALL MODELS | 1133, 0485                                                                                 |
| Rowa                | ALL MODELS | 0490, 1030                                                                                 |
| <b>S</b> Saba       | ALL MODELS | 0457                                                                                       |
| Sabaki              | ALL MODELS | 0484                                                                                       |
| Salora              | ALL MODELS | 1136                                                                                       |
| Sampo               | ALL MODELS | 1148, 1130, 0986, 1029                                                                     |
| Samsung             | DVD511     | 1130                                                                                       |
| Samsung             | DVDM301    | 0464                                                                                       |
| Samsung             | DVDP231    | 0464                                                                                       |
| Samsung             | DVDP421    | 0464                                                                                       |
| Samsung             | DVDS221    | 0464                                                                                       |
| Samsung             | DVDS321    | 0464                                                                                       |
| Samsung             | DVDV1000   | 1107                                                                                       |
| Samsung             | DVDV2000   | 1107                                                                                       |
| Samsung             | DVDV2500   | 1107                                                                                       |
| Samsung             | DVDV3500   | 1107                                                                                       |
| Samsung             | ALL MODELS | 1016, 1129, 1126, 0464, 0447, 0452, 1107, 0466, 0446*, 1076, 1072                          |

| MANUFACTURER    | MODEL      | CODE                                     |
|-----------------|------------|------------------------------------------|
| Sansui          | CDVD2500   | 0456                                     |
| Sansui          | VRDVD4000  | 0456                                     |
| Sansui          | ALL MODELS | 0456, 0484, 1069, 1134, 1045, 1046       |
| Sanyo           | DMW1000    | 1137                                     |
| Sanyo           | DMW360     | 0436                                     |
| Sanyo           | DMW380     | 0436                                     |
| Sanyo           | DVD1100    | 0436                                     |
| Sanyo           | DVD1500    | 0436                                     |
| Sanyo           | DVD5010    | 0436                                     |
| Sanyo           | DVD6000    | 0436                                     |
| Sanyo           | DVD6040    | 0436                                     |
| Sanyo           | DVD6070    | 0436                                     |
| Sanyo           | DVD7000    | 0436                                     |
| Sanyo           | DVD9201    | 0436                                     |
| Sanyo           | DVD9501    | 0436                                     |
| Sanyo           | DWM1000    | 1137                                     |
| Sanyo           | RB470MT    | 0436                                     |
| Sanyo           | RBDMW770   | 1137                                     |
| Sanyo           | ALL MODELS | 1154, 0436, 0827, 0456, 0878, 1137, 0476 |
| Scan            | ALL MODELS | 1152, 0884, 1056                         |
| ScanMagic       | ALL MODELS | 1113                                     |
| Schaub Lorenz   | ALL MODELS | 1069, 1134, 1114                         |
| Schneider       | ALL MODELS | 0884, 0881, 0878, 1005, 1114, 0457       |
| Schwaiger       | ALL MODELS | 0986                                     |
| Scientific Labs | ALL MODELS | 0484                                     |
| Scott           | ALL MODELS | 1144, 0437, 0457                         |
| SEG             | ALL MODELS | 1141, 0484, 1124                         |
| Shanghai        | ALL MODELS | 0437                                     |
| Sharp           | DV740U     | 0986                                     |
| Sharp           | DVS1U      | 0491                                     |
| Sharp           | ALL MODELS | 0491, 0986, 0456, 0480, 1017             |
| Sherwood        | ALL MODELS | 1132, 1136, 0460, 1026                   |
| Shinco          | DVD868     | 1132                                     |
| Shinco          | ALL MODELS | 1132, 0460                               |
| Shinsonic       | ALL MODELS | 0469, 0460, 1015, 1132                   |
| Silva           | ALL MODELS | 1005, 1114                               |
| Simaudio        | ALL MODELS | 1087                                     |
| Singer          | ALL MODELS | 1152, 1045, 1046                         |
| Skymaster       | ALL MODELS | 0484, 1113                               |
| Slim Art        | ALL MODELS | 1069, 1134                               |
| SM Electronic   | ALL MODELS | 1152, 0484, 1113                         |
| Smart           | ALL MODELS | 0884, 1124                               |
| Sonic Blue      | ALL MODELS | 1136                                     |
| Sony            | DAVS300    | 1015                                     |
| Sony            | DVPC670D   | 0469                                     |
| Sony            | DVPF21     | 0469                                     |
| Sony            | DVPNC600   | 0469                                     |
| Sony            | DVPNS300   | 0469                                     |
| Sony            | DVPNS315   | 0469                                     |
| Sony            | DVPNS325   | 0469                                     |
| Sony            | DVPNS415   | 0469                                     |
| Sony            | DVPNS425P  | 0469                                     |
| Sony            | DVPNS700   | 0469                                     |
| Sony            | DVPNS715   | 0469                                     |
| Sony            | DVPNS725P  | 0469                                     |
| Sony            | DVPS560D   | 0469                                     |

| MANUFACTURER         | MODEL      | CODE                                                                    |
|----------------------|------------|-------------------------------------------------------------------------|
| Sony                 | SLVD100    | 1118                                                                    |
| Sony                 | SLVD300P   | 1118                                                                    |
| Sony                 | ALL MODELS | 1018, 0469, 1015, 0464, 0827, 0024*, 0443, 1118                         |
| Soundmaster          | ALL MODELS | 0484                                                                    |
| Soundmax             | ALL MODELS | 0484                                                                    |
| Soundwave            | ALL MODELS | 0881                                                                    |
| Standard             | ALL MODELS | 0484, 0457                                                              |
| Starmedia            | ALL MODELS | 1145, 1058                                                              |
| Sungale              | ALL MODELS | 1139                                                                    |
| Sunwood              | ALL MODELS | 1114                                                                    |
| Supervision          | ALL MODELS | 0484, 1113                                                              |
| SVA                  | ALL MODELS | 0437                                                                    |
| Sylvania             | DVC860D    | 0487                                                                    |
| Sylvania             | DVL100     | 0487                                                                    |
| Sylvania             | ALL MODELS | 0487*, 1074*, 1107, 0446                                                |
| Symphonic            | ALL MODELS | 1074, 0487*                                                             |
| Synn                 | ALL MODELS | 0484                                                                    |
| <b>T</b> Tag McLaren | ALL MODELS | 1091                                                                    |
| Tandberg             | ALL MODELS | 1124                                                                    |
| Tandy                | ALL MODELS | 0658*                                                                   |
| Tatung               | ALL MODELS | 1069, 1134, 0466                                                        |
| Teac                 | ALL MODELS | 1132, 1136, 0438, 0871, 0872, 0882, 0453, 0894, 1135, 0460, 0484, 0878  |
| Technics             | ALL MODELS | 1096, 1151, 0445, 0479, 1020, 0452, 1136, 0434, 0488, 1011              |
| Technika             | ALL MODELS | 1069, 1134, 0482                                                        |
| Te chwood            | ALL MODELS | 0894, 1135, 1124                                                        |
| Tensai               | ALL MODELS | 1152, 0457                                                              |
| Tevion               | ALL MODELS | 0484, 0457                                                              |
| Thakral              | ALL MODELS | 0438                                                                    |
| Theta Digital        | ALL MODELS | 0870, 0453, 0435                                                        |
| Thompson             | ALL MODELS | 0450, 0441                                                              |
| Thomson              | ALL MODELS | 1120                                                                    |
| Tokai                | ALL MODELS | 1130, 1141, 1114                                                        |
| To kaido             | ALL MODELS | 1130                                                                    |
| To kiwa              | ALL MODELS | 0884                                                                    |
| To shiba             | SD1200     | 0451                                                                    |
| To shiba             | SD1800     | 0451                                                                    |
| To shiba             | SD2150     | 0451                                                                    |
| To shiba             | SD2705     | 0451                                                                    |
| To shiba             | SD2800     | 0451                                                                    |
| To shiba             | SD2900     | 0451                                                                    |
| To shiba             | SD3750     | 0451                                                                    |
| To shiba             | SD3800     | 0451                                                                    |
| To shiba             | SD3900     | 0451                                                                    |
| To shiba             | SD3960     | 0451                                                                    |
| To shiba             | SD4700     | 0451                                                                    |
| To shiba             | SD4900     | 0451                                                                    |
| To shiba             | SDP2500    | 0451                                                                    |
| To shiba             | SDV280     | 0451                                                                    |
| To shiba             | SDV290     | 0451                                                                    |
| To shiba             | SDV291     | 0451                                                                    |
| To shiba             | ALL MODELS | 0463, 0456, 0925, 0451*, 0477, 0472, 0478, 0892, 0452, 0480, 1104, 1071 |
| Trans-Continents     | ALL MODELS | 1141                                                                    |

| MANUFACTURER        | MODEL      | CODE                                                                                     |
|---------------------|------------|------------------------------------------------------------------------------------------|
| Tredex              | ALL MODELS | 0484, 1102                                                                               |
| TView               | ALL MODELS | 1143                                                                                     |
| <b>U</b> Umax       | ALL MODELS | 1152                                                                                     |
| United              | ALL MODELS | 1141, 1113, 0878                                                                         |
| Universum           | ALL MODELS | 1136, 1124                                                                               |
| Urban Concepts      | ALL MODELS | 0451                                                                                     |
| US Logic            | ALL MODELS | 0460                                                                                     |
| <b>V</b> V inc      | ALL MODELS | 1125                                                                                     |
| Venture             | ALL MODELS | 0878*, 1065, 0491                                                                        |
| Vieta               | ALL MODELS | 0884                                                                                     |
| Voxson              | ALL MODELS | 1005, 1113                                                                               |
| <b>W</b> Walkvision | ALL MODELS | 1132, 0460                                                                               |
| Welkin              | ALL MODELS | 1005                                                                                     |
| Wesder              | ALL MODELS | 1129                                                                                     |
| Wharfedale          | ALL MODELS | 1130, 0986, 1121, 1045, 1046                                                             |
| Windy Sam           | ALL MODELS | 0464                                                                                     |
| <b>X</b> XLogic     | ALL MODELS | 1069, 1134, 1144, 0484                                                                   |
| XMS                 | ALL MODELS | 1123, 1114                                                                               |
| Xoro                | ALL MODELS | 1052                                                                                     |
| Xwave               | ALL MODELS | 1119                                                                                     |
| <b>Y</b> Yamada     | ALL MODELS | 1030                                                                                     |
| Yamaha              | ALL MODELS | 0462, 0471, 0439, 0869, 0481, 0482,<br>0473, 1027, 1023, 1100, 1066, 1086, 0452,<br>0463 |
| Yamakawa            | ALL MODELS | 1141                                                                                     |
| Yukai               | ALL MODELS | 1113                                                                                     |
| <b>Z</b> Zenith     | DVB312     | 1136                                                                                     |
| Zenith              | XBV342     | 1081                                                                                     |
| Zenith              | ALL MODELS | 1081*, 1136, 1097, 0475, 0451                                                            |

\*combo model (DVD/VCR or DVD/TV or DVD/VCR/TV)

B9376-0922

©2003, 2004 Viacom International Inc. All Rights Reserved. ?

Nickelodeon, Nick Jr., Dora the Explorer and all related titles, logos and characters are trademarks of Viacom International Inc.

InteracTV is a mark of Beep Telecommunications and Computing, L.L.C. Used under license.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., New York, New York 10010 U.S.A.

PRINTED IN CHINA.

Manufactured for Fisher-Price. ©2003, 2004 Mattel, Inc. All Rights Reserved.

Fisher-Price and the Fisher-Price logo are U.S. trademarks of Mattel, Inc.

Packaging and address should be retained for future reference.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-888-892-6123.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe,

Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-Toys.

 Questions or Comments?  
1-888-892-6123

**Fisher-Price®**  
ITEM NO. B9376