






Quick Start

- 1 Turn power on 
- 2 Select swing speed 
- 3 Push seat to start swinging



- 4 Select music  or sounds 

©2011 Mattel. All Rights Reserved.